

DE Fenster-Kit installieren

Das Fenster-Kit ist zum abdichten von Flügel- und Dachfenstern vorgesehen. Zur Installation gehen Sie Folgendermaßen vor:



Beachten Sie auch die Hinweise in der Bedienungsanleitung zum TECHNIPOLAR 1

Fig. 1



Kleben Sie das Klett-Band auf den Fensterrahmen.

Fig. 2



Kleben Sie das Klett-Band auf den Rahmen des Fensters.

Fig. 3



Kürzen Sie das Klett-Band an den Ecken.

Fig. 4



Achten Sie darauf, dass die Ecken bündig aneinander liegen.

Fig. 5



Befestigen Sie die Fensterabdichtung.

Fig. 6



Achten Sie darauf, dass beide Hälften gerade zueinander ausgerichtet sind.

Fig. 7



Öffnen Sie den Reißverschluss an der Seite.

Fig. 8



Stecken Sie den Abluftschlauch in die entstandene Öffnung und schließen Sie den Reißverschluss.

EN Installing the window kit

The window kit is designed to seal tilt windows. To install proceed as follows:



Please read also the notes in the TECHNIPOLAR 1 manual.

Fig. 1



Glue the Velcro tape to the window frame.

Fig. 2



Glue the Velcro tape to the frame of the window.

Fig. 3



Shorten the Velcro tape at the corners.

Fig. 4



Make sure that the corners are flush.

Fig. 5



Attach the window seal.

Fig. 6



Make sure that both halves are aligned with each other.

Fig. 7



Open the zipper at the side.

Fig. 8



Insert the exhaust hose into the opening and close the zipper.